

MAiNNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616
Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

MW-705D Innovator BT GPS watch



MAiNNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel:+886 2 8953-6616

Web:www.mainnav.com E-mail:info@mainnav.com Fax:+886 2 8951-8531

BT GPS Watch Manual

Introduction	4
Sports watch SPEC	5
Product Feature	5
Technical Spec	5
GPS SPEC	5
Heart rate sensor	5
Accessory	6
Quick start use	7
GPS	7
GPS status	7
GPS log	7
GPS landmark	7
GPS setting	7
Heart rate monitor	7
Pace / Pedometer	7
Timer	7
Bluetooth	7
Warning alarm	7
Data log / Position recorded	7
Setting	8
Date / Time	8
Alarm	8
Temperature	8

MAiNNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Time format	8
Contrast	8
Back light	8
Power saves	8
Language	8
Firmware version	8
Factory reset	8
Bottom intro	9
Note	10
GPS --Acquiring GPS signal	10
Power saves	10
Bluetooth function	10
Heart-rate sensor	10
(GPS)Location recorded	10
Reset	10
Watchstrap	10
Battery operating time	10
Setting	10
Watchband	11
Bike mounting	12
Main unit instruction-- Getting Start	15-28
Warranty	29

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Introduction

Our innovator MW-705D is a watch that tells you where you are--not only does it tell time but also saves time by showing you the right path. This state of the art device MW-705D watch with particular rugged new looking and cutting-edge GPS technology (GPS watch +Bluetooth), the new innovator MW-705D watch solves all your problems for sporting and traveling.

The most distinguish part is this All-in-one GPS watch mark with BT function. While you turn on the BT function, it turns out to be a BT receiver. You might pair with your BT device for navigation. Watch combine with our navigation technology, raising the GPS to next level.

For data logger's part, this unit that records NMEA position data from a GPS. It is really convenient, economical alternative to using a laptop computer or PDA, especially on long road. Simply connect the logger to a GPS during your trip then download the track data to a PC.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Sport watch spec

Screen Display-- LCD 128 X128 (pix)

Heart-rate —Using IR sensor

Speed +Distance Sensor ,Temperature sensor

countdown timer, Alarm reminder

Pedometer/pace

Watch Physical size: 69 X55X23.5(mm) Weight 75g

SPP Bluetooth 2.0 transmission 10 meters

Water resistant (IPX7)

GPS log

Store up to 120,000 waypoints

Position recorded -- 256 sets

GPS +Bluetooth always on: around 6.5 hours

GPS data log on: 8.5 hours

Standby mode --380 hours

Battery: Li-ion 400 mA/h

Power consumption: 40mA

Power

input voltage: 5V

Charger interface: mini USB

Operating time : -20°C ~60°C

storage temperature:: -30°C ~80°C

GPS

GPS: High sensitivity SiRF Star III LP chip

1) Acquisition: 20 channel parallel

2) Tracking: up to 12 satellites

3) Update rate: 1 second

4) Acquisition time

Reacquisition 0.1 sec, averaged

Snap start 3 sec, averaged

Hot start 6 sec, averaged

Warm start 38 sec, averaged

Cold start 42 sec, averaged

Product Feature

Bluetooth-- transmission GPS signal to any devices (PDA, smart phone and so on) for Navigation.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Equipped with GPS SiRF star III
Separation of watchband
Bike mounting
Time correction
Altitude/elevation data GPS- provided altitude with vertical
Comfortable, adjustable and flexible strap
Smart Power Saving mode
1-year warranty
Record track-logs of vehicle movement
Display Max speed , Average Speed , distance and moved time
User can select among Google Map, Satellite or Hybrid to show the track
Reads NMEA data from GPS
Replay the recorded routes/ time/ speed... point by point
suitable for hiking, biking and walking
Accessory
✓ Gift box
✓ Innovator GPS watch
✓ CD
✓ USB interface charger
✓ Travel charger
✓ Owner's manual
✓ Lanyard
✓ Bike mounting
✓ Magnet
✓ Small Tool for open charger cover

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531


GPS watch -Quick Use

Before using watch, please fully charge about 3 hours, the mini-USB port is on the right side of watch, use our tool open it.

Press mode to turn on the watch, press mode to turn off the watch (about 5 seconds)

Main menu

GPS



GPS status: Enter GPS and press **up** to acquire satellite signal GPS.

You could view Moved Time/Moved DST and Avg. Speed/Max.Speed

GPS log: for GPS data it can save 256 sets record, press “set/clr” about 3 seconds to record it. In GPS log you could check log status, log list, Record memory and delete all log record.

1. *Log status*—press “on” to start record your route. Press “off” to stop logging.

2. *Log list*—in the log list you could check GPS data which you recorded.

3. *Rec .memory*---Check the capacity of memory

4. *Del. all log*---Delete all your log record.

GPS landmark: You could save your landmark in here

New landmark: press “set/clr” 3 seconds to record new landmark.

Landmark list: check landmark list in here

Delete Landmark: Delete your entire landmark record here.

GPS setting:

In GPS setting: you could check time zone, unit format and time regulate.

Time zone—Adjust the right time , your local time (UTC)

Unit format—you could choose imperia and Metric

Time regulates—You could update the correct time and date in here.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Heart rate sensor

Put your finger on the sensor (Please press on it gently); press about 12 seconds to calculate your heart beating.

Pedometer

Enter Pace function, press **up** to start counting pace

Timer

Enter timer function, press **up** to start and press down to record it

Bluetooth: Turn BT on/off. Turn BT on and pairing your device for navigation. The pass word for pairing is **"0000"**.

Warning alarm

In warning alarm, you could view Speed, temperature and alarm reminder
Speed—set up your speed per hour, once you reach this speed, it will sound and warn you.

Temperature: Set the temperature (temperature range is $-20^{\circ}\text{C} \sim 130^{\circ}\text{C}$)

Alarm reminder: Press mode and switch to warning alarm and enter it.

Choose on or off. Choose "on" watch will sound in every hour.

Setting: while you setting any function please press **set/clr** about 3 seconds (wait for processing).

Date/Time: set the correct date and time

Alarm: On/off, switch to **on** and press **set/clear** to set the time

Temperature: Fahrenheit/ Celsius

Time format: AM/PM

Language: English, traditional Chinese and Simplified Chinese

Contrast: Press down or up to adjust word brightness. The more number, the word is more brightness

Factory reset: press set/clear about 3 seconds waits for fully processing

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel:+886 2 8953-6616

Web:www.mainnav.com E-mail:info@mainnav.com Fax:+886 2 8951-8531

Bottom Intro

Mode
Press mode to turn on/off the watch Press mode to main menu Press mode to switch other page Press mode to exit menu
Set/CLR
press to enter the function press to set up any function
UP
Scroll to select function Press up to start /press up to stop Press up to exist the function
Down
Scroll down to select function
Reset
When GPS can't fix the satellite or unit crash down, please press reset to get back factory setting.



MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Note

GPS --Acquiring GPS signal

Press Main manual and Switch to GPS. Enter GPS status-- go outdoors and press “up” to acquire satellite signal. For cold start is about 45 seconds.

Power save

Choose power save “on” means when you turn on GPS (BT) whether it get GPS fixed or not within 10 minutes, it will automatically off. This way could save power.

Choose power save off— Once you turn on GPS (BT), it will not off automatically unless you turn it off

Bluetooth

Bluetooth only for transmission GPS signal to any devices (PDA, Smart phone and so on) for Navigation.

Hear-rate sensor

Our heart rate is using IR (infrared) sensor. It's easy to use You can measure your heart beating in any time. Once you want to check your heart rate, enter heart rate function then put your finger on IR sensor (on the bottom of watch). Please gently and slightly put your finger on it.

GPS Landmark recorded

Go to any place where you want to mark a location and save your position. It can save 256 records.

Reset

It's on the left side of watch. When GPS can't fix the satellite or unit crash, please press reset to get back factory setting.

Battery operating time

GPS +Bluetooth always on: around 6.5 hours

GPS datalog on: 8.5 hours

Stand by mode (GPS , BT and data logger is off) 380 hours

Battery: Li-ion 400 mA/h

Setting

While you set any record in setting part, you should press “set/clr” about three seconds, wait for processing, like the following picture

MAiNNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531




Watchband

Our Watchstrap can separate from main unit. You may use our lanyard and




hang it on your neck whiles you training.

Take apart the watchband




Put them together




Bike mounting install instruction

Accessories




2. How to install the holder

1.1 put the holder in circle part



1.2 Fixing the mounting on the bike by using screw



3. How to fix on handlebars

step 1 :

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531



Step 2




MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Step3



4 - Finish attachment



MAINNAV International Corp.


11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531


Getting start

Front page: In this page you will see battery life, temperature, time and date. If you turn on the back light, the left top of screen will show small bulb.

Back light is on



Main manual— Press mode to main manual, scroll up and down, switch to any function you need.



GPS

Press mode and switch to GPS function.

Press **set/clr** enter GPS function: In this page you can check GPS status, GPS log, GPS landmark and GPS setting.



Press **set/clr** enters GPS status-- Go outdoor or window and press **up** to acquire satellite signal.

When GPS satellite is fixed, the left top of screen has Antenna sign which means GPS is on and fixed.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel:+886 2 8953-6616

Web:www.mainnav.com E-mail:info@mainnav.com Fax:+886 2 8951-8531



(GPS instant message) you could check the bellowing message in GPS status


Enter GPS status press **set/clr** you could check GPS status(page 1), press “**set**” check average move time / average move distance (page2), press “**set**” check average speed /maximum speed (page 3), press set you could view speed and elevation. Press “down” the page will change automatically.

(While you biking you could use this mode—page 4 to view your speed)




(Note: in page 4 --biking mode, if you did not meet the average speed ,the Arrow will face down, if your speed meets average speed the arrow will be up.)

Turn off the GPS, please press **up** to exit. The left top of Antenna is gone which means GPS is off.



GPS log

Switch to GPS log and press **set/clr** enter log status.




Start to log your journey in this page ,press **set/clr** about 3secs , it will show On/off

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616



Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Press “on” to start logging, the top screen will show the flag




Log list

Switch to GPS log and press **set/clr** enter to log list, press up and down select data record that you want to check and press **set/clr**



Press **set/clr** to view next page



the right bottom of number means you view the first record, press set/clr to view moved time/destination

Press set/clr to view Avg speed and Max speed

Note: when using GPS log function, please make sure GPS is fixed. Once you want to check log list, you should turn off GPS and GPS log function.


Rec. memory

Switch GPS and select Rec. memory and press “set/clr” Check memory capacity

MAiNNAV International Corp.


11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531



Del.all log

Switch to "del. all log" press "set/clr" to enter it . It will show you "YES" .To delete all your record press "set" about 3 seconds.



If you want to delete all your record press "set/clr" about 3 seconds. All you record will delete.


GPS landmark

Switch to GPS press **set/clr** and enter to GPS landmark



To record your position (landmark) there are two way can do

1.



After fixed GPS position, press **set/clr** 3 secs. Then it will record your landmark

2.



or enter GPS landmark press **set/clr** to New landmark list , press set about 3 seconds to record it

Landmark list



Enter GPS landmark, you could check Landmark list in here, press up or down select GPS data you want to check. (The right bottom number show you view

MAINNAV International Corp.


11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

the first record)



Delete landmark Switch to GPS landmark press **set/clr** enter del. landmark. Press **set/clr** it will show "YES", press set about 3 seconds to delete all record.



Personal info




Press mode to GPS press **set/clr** enters Personal info. In this page, you could see how far you have ride (walk) **Example:** record position in A place then you ride to B place, you could check how far from A to B

Enter the personal info you could see the following, you could save 16 landmark records compare to your present position.



Enter person info press **set/clr** 3 seconds enter the the right page



Press up or down to choose any mark sign you need, then press **set/clr** 3 secs to record it.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616


Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

GPS setting

In GPS setting, you could set time zone, unit format and time regulate


Time zone

Setting (UTC) Time zone, please adjust your local time.




Setting unit format

Switch to GPS setting and enter unit format, you could select Imperial or Metric.



Time Regulate

Enter time regulate, and press **set/clr** about 3 seconds, then it will update the correct time and date.




Heart rate

Press mode to main manual and switch to heart rate function press **set/clr**
-enter Heart rate function


MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel:+886 2 8953-6616

Web:www.mainnav.com E-mail:info@mainnav.com Fax:+886 2 8951-8531




Press **set/clr** and put your finger on heart rate sensor, (smoothly and gently). It starts to calculate you're heart beating.





Wait about 12 second. Then you will see the result like the following example.

Pace



Press mode to main manual and switch to pace.

Enter the pace function, Press **up**, you will see the little man on the top of screen, then you can start to measure your pace




MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel:+886 2 8953-6616



Web:www.mainnav.com E-mail:info@mainnav.com Fax:+886 2 8951-8531

The result will show on the bottom of screen.





Timer

Press mode to main manual and switch to timer. Press **set/clr** enter timer function. Press **up** to start and press **up** to stop




Press **down** to record. It can save 4 sets of record



Bluetooth

Press mode to main manual and switch to Bluetooth function. Press **set/clr** and enter BT function, switch to on or off.




Press **Set/clr** (3 seconds wait for processing) to start Bluetooth function. If Bluetooth is on, the top of screen will show BT mark.


MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531



Turn the BT off, please switch off and press **set/clr** about 3 seconds



Warning alarm

Press mode and switch to warning alarm press **set/clr** to enter speed. In this function you could set up your speed, once you reach this speed, it will sound to warn you. If you don't want to use this function, set the number zero, it will stop.



Setting your speed, it will warn you once you over speed.

Temperature

Press mode and switch to warning alarm and press **set/clr** enter it, press up and down to set the temperature (temperature range is -20°C ~ 130°C) once you set up the temperature press **set/clr** 3 seconds to record it. Stop this function please set the temperature 0°C .



MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Alarm reminder

Press mode and switch to warning alarm and press **set/clr** enter it. Choose on or off. Choose "on" watch will sound in every hour.



Setting

Press mode to main manual and switch to **setting**. While you setting any record, you should press **set/clr** about 3 seconds and wait for processing like the left picture





Date/time

Press **set/clr** enter Date/Time

Press **up** and **down** to adjust the correct date and time then press **set/clr**.

Press **set/clr** to move year, month, date and time



After set the correct time press **set/clr** (about 3 seconds) to record it.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Alarm: On/off




Switch to setting press **set/clr** enter alarm function.



(About 3 seconds wait for processing)

When you using this function, please choose 24 hours (time format)

Choose alarm on or off. Once you choose on or off, press **set/clr** (3 seconds) to record it.



After processing then enter the alarm format. Press **up** and **down** to set the correct time, presses **set/clr** to move hour, minute and second.



After you finish all setting, please press **set/clr** (about three seconds) to record it.

Temperature




Switch to setting press **set/clr** enter temperature

Choose Fahrenheit or Celsius then press **set/clr** about three seconds to record it.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel:+886 2 8953-6616

Web:www.mainnav.com E-mail:info@mainnav.com Fax:+886 2 8951-8531





Time format




Switch to setting press **set/clr** enter Time format.

Choose AM/PM or 24HR, and then press **set/clr** (3 seconds) to record it.



Contrast

Switch to contrast press **set/clr** enter it. Press **down** or **up** to adjust word brightness. The number is high, the word is more brightness





Back light

Switch to setting press **set/clr** and enter back light function. Press up and down and select amount of time the back light will stay on. There are four options 15 seconds, ,30 seconds,60 seconds and always on.

MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel:+886 2 8953-6616

Web:www.mainnav.com E-mail:info@mainnav.com Fax:+886 2 8951-8531




Language



Switch to setting press **set/clr** and enter language function.

There are three Languages can choose—English, traditional Chinese and Simplified Chinese. Press up and down choose your language then press **set/clr** about three seconds to record it.




Power saves

Press mode and switch setting press **set/clr** enter it.

Choose on/off, and press **set/clr** about three seconds to record it

Choose power save “on” means when you turn on GPS (BT) and it doesn't get position fix within 10 minutes, it will automatically off. This way could save power.

Choose power save off—GPS (BT) will not off automatically unless you turn it off





MAINNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Firmware

Enter setting and switch to firmware. You could check firmware version





Factory reset



Press mode switch to setting then press **set/clr** enter factory reset function.

Back to the original setting (factory status) please enter factory reset, when it shows YES, press **set/clr** about 3 seconds to record it.



MAiNNAV International Corp.

11F, 293-1, Sec. 1, Zhongshan Rd., Banqiao City, Taipei 220, Taiwan, R.O.C. Tel: +886 2 8953-6616

Web: www.mainnav.com E-mail: info@mainnav.com Fax: +886 2 8951-8531

Warranty information

Mainnav values your business and always attempts to provide you greatest of service.

Our product warranty is to be free from defects in material and workmanship during the warranty period. If the product confirms to be defective in material within one year, we will be repair or replace the product.

All of our Products are warranted for one year, and accessory is warranted for six months. (Note: battery is warranted for 3 months). One way freightage is responsible for the customer.

The warranty does not cover:

1. Any product of serial number has been defaced modified or removed.
2. Damage, deterioration or malfunction resulting from accident, misuse, water or other acts of nature. Failure to follow instructions supplied with the product.
3. For our products sold outside of oversea, please contact your dealer (distributor) directly for warranty service.